

INSTALLATION

SOILTEX AND MULTICO

Please follow these step-by-step installation instructions for the best results

1



EXAMINATION

Ensure your arena has a firm base and good drainage. No fibre additive will "fix" a poorly constructed arena.

2



LEVELLING

Install and / or level your sand to a depth of 75 - 80mm. Too much sand may cause shifting in the surface.

3



PREPARATION

Divide the arena into several even sections. Equal to the number of bales supplied. For an uneven number - keep 1 x bale aside.*

4



SPREADING

Place 1 x bale in each section. Open the bale, loosen the fibres and spread the entire bale within the section.

5



IRRIGATION

Irrigate the surface to let the fibres soak. For an indoor situation, overnight if possible.

6



BLENDING

With a Rotary Hoe or Harley Rake blend the fibres into the top 50mm of sand. You may need to do a second or third pass.

*Use the extra bale to spread over any lean areas prior to blending